

MAINTENANCE

CLEANING AGENTS SUITABLE FOR RUBBER FLOORING



Broom



Wet Mop



Wet/Dry Vacuum



Buffer



Steam Vac



Tornado

I. CLEANING INSTRUCTIONS

INITIAL CLEANING

1. Remove all surface soil, debris, sand and grit with a vacuum.
2. Scrub floor with a neutral detergent.
3. Pick up solution with a wet vacuum, rinse with clean water and allow to dry thoroughly.
4. This process maybe done in one or two steps with an industrial floor cleaner.

DAILY/REGULAR CLEANING

1. Sweep or vacuum floor to remove surface soil, debris, sand and grit.
2. Damp mop the floor
3. This process may be done in one or two steps with an industrial floor cleaner.
4. Allow floor or dry thoroughly.

INTERIM MAINTENANCE

1. Vacuum floor thoroughly.
2. Aggressively scrub the floor with a neutral detergent. Use the rotary scrubber or industrial floor cleaner.
3. Vacuum any remaining soiled solution with a wet/dry vacuum.
4. Allow floor to dry thoroughly.

RESTORATIVE MAINTENANCE

1. Vacuum floor thoroughly.
2. Scrub using a rotary scrubber or an industrial floor cleaner. and neutral cleaner.
3. Pick up solution with wet vacuum or steam vacuum.
4. Allow floor to dry thoroughly.

GENIEMAT[®] FIT

MAINTENANCE INSTRUCTIONS



MAINTENANCE

II. Equipment Specifications

STEAM VACUUM MACHINE	Includes a scrubber and vacuum.
POWER SCRUBBER	430 mm rotary floor buffer with mounted detergent tank and feed line to the brush. A circular brush attachment should be used.
WET/DRY SHOP VACUUM UNIT	Power Unit: Minimum 1.7 hp commercial unit, 7.0 amp, 120V AC, 50/60 Hz two stage bypass motor. Tank Capacity: 10-25 gallon, lined stainless steel or polypropylene. Accessories: Extension wand with a 150 mm to 300 mm in pickup nozzle, crevice tool, heavy-duty extension cord.
DETERGENT	Similar to any Hoover SteamVac model with scrubber and vacuum.

IMPORTANT MAINTENANCE TIPS

- Use high CFM vacuum to pick up dust.
- For large areas, use the industrial floor cleaner.
- Dilute the detergents with water per the manufacturer's instructions; use higher concentrations for stubborn stains or hard to clean areas.
- Rinse, wet vacuum or mop up any detergent residue when cleaning the floor.
- For gum, use generic gum remover, however, any solvent-based product should be rinsed well with water to avoid damaging floor.
- **DO NOT** use an Auto Scrubber with a squeegee attachment. It tends to not pick up all of the dirty water solution and leaves a film of diluted dirty water on the tiles.
- **DO NOT** use petroleum or citrus based detergents.

CONTACT US

For Your Project Specific Questions

Australia +61 3 9018 7696 | **Middle East** +971 4 813 5501 | **UK** +44 203 9846444
E. info@pliteq.com.au

© Pliteq Asia Pacific PTE LTD. 2021.

The information provided is accurate to the best of our knowledge at the time of issue. However, we reserve the right to make changes when necessary without further notification. Suggested application may need to be modified to conform with local building codes and conditions. We cannot accept responsibility for products that are not used, or installed, to our specifications. All listed dimensions are nominal.



www.pliteq.com.au